

Okay guys this is the basic ATO set up notice that the supply container is higher than the sump so im not sue why or how the water keeps flowing after the pump shuts off

